



QUICK START



Cisco Unified IP Phone
9951 and 8961

- 1 Dial
- 2 Hang up
- 3 Answer
- 4 Mute
- 5 Hold
- 6 Forward All
- 7 Do Not Disturb
- 8 Conference
- 9 Transfer
- 10 Divert
- 11 Call History
- 12 Directories
- 13 Shared Lines
- 14 Voicemail
- 15 Tips



Note For best results, print on 8.5 x 14" (legal-sized) paper.


1 Dial

To dial, lift the handset and enter a number. Or:

- Press an unlit session button (right side).
- Press the **New Call** softkey.
- Press the (unlit) headset button or speakerphone button .

Dial from call history

As you enter a phone number, matching numbers display from your call history.



To dial, scroll to a number and press the **Select** button in the Navigation pad or the **Call** softkey.

Redial the last number

Press the **Redial** softkey.

Speed dial

Press a speed-dial button (if available). Or, enter a speed-dial code while on-hook (no dial tone), then press the **Speed Dial** softkey.

Your system administrator can help you set up speed dials from your User Options web pages.

2 Hang up



To end a call, replace the handset. Or:

- Press the **Release** button .
- Press the **End Call** softkey.
- Press the (lit) headset button or speakerphone button .

3 Answer


To answer a ringing call , lift the handset. Or:

- Press the flashing amber session button (right side).
- Press the **Answer** softkey.
- Press the (unlit) headset button or speakerphone button .
- Press the **Select** button in the Navigation pad.



Call waiting

If you get a second call while the first call is active, a second session label displays.



To connect the second call and put the first call on hold automatically, press the flashing amber session button (right side).

Multiple lines

If you use multiple lines, keep these basics in mind:

- Press the **All Calls** button to see all calls on all lines (oldest first). Otherwise, your phone displays calls that are on the selected line only. All Calls is recommended for multiple lines.

- To see which line is selected, look for a blue icon on the line label and the line extension in the header bar. (All Calls uses your primary extension.)



- Press a line button or **All Calls** at any time to switch views; doing so does not affect calls.

4 Mute

Press the **Mute** button to toggle Mute on and off. When Mute is on, the Mute button glows red.

5 Hold



1. Press the **Hold** button .
- The hold icon displays and the session button pulses green.
2. To resume the highlighted call, press the pulsing green button , the **Resume** softkey, or the Navigation pad **Select** button.

6 Forward All

1. Press the **Forward All** softkey.
2. Enter a phone number, select a number from Call History, or press the **Messages** button (to forward to voicemail).
3. Look for Forward All icon on your screen.
4. To cancel call forwarding, press the **Forward Off** softkey.



Your system administrator can help you forward calls remotely from your User Options web pages.

7 Do Not Disturb

Press the DND button (if available) to toggle DND on  or off .

When on, Do Not Disturb (DND) mutes the ringer and may block visual notification for new calls.

8 Conference




1. From a connected call  (not on hold), press the **Conference** button .
2. Make a new call.
3. Press the **Conference** button or the **Conference** softkey (before or after the party answers).

The conference begins and the phone displays “Conference” instead of caller ID.



4. Repeat these steps to add more participants.
- The conference ends when all participants hang up.

“Conference in” a held call

1. From a connected call  (not on hold), press the **Conference** button .
2. Press the pulsing green session button  for the held call that you want to add.



Or, if the held call is on another line, press the **Active Calls** softkey, choose a call from the list, and press the **Conference** softkey.

The conference ends when all participants hang up.

View & remove conference participants

During a conference, press the **Show Details** softkey. To remove a participant from the conference, highlight a name and press **Remove**.

9 Transfer

1. From a connected call  (not on hold), press the **Transfer** button .
2. Call the transfer recipient.
3. Wait for the recipient to answer, or skip to Step 4 while the call is ringing.
4. Press the **Transfer** button or the **Transfer** softkey.


The transfer is complete. Confirmation displays on your phone screen.

10 Divert




Press the **Divert** softkey to redirect a ringing or active call to voicemail or to another phone number (set up by your system administrator). You must resume a held call before you can use **Divert**.

Divert affects the highlighted call only. If necessary, scroll to the call before pressing **Divert**.

11 Call History

Press the **Applications** button  and select **Call History**.



The last 150 calls display:

- Missed calls 
- Placed calls 
- Received calls 

To dial, scroll to a call and press the **Select** button in the Navigation pad or the **Call** softkey.


To view details for a call, highlight the call and press these softkeys: **More** > **Details**.

View new missed calls

Press the session button  next to the **Missed Calls** icon  on the right side of the screen (may include a count of missed calls). The **Missed Calls** icon displays in this location when you have new (not yet viewed) missed calls.



Or, view your missed calls history by opening call history and pressing the **Missed Calls** softkey.

12 Directories

1. Press the **Contacts** button  and select a directory.
2. Enter search criteria and press **Submit**.
3. Select the listing and press the **Dial** softkey.


13 Shared Lines

If you share a line with your co-worker:

- Either you or your co-worker can answer a ringing call on the shared line.
- When your co-worker has a call on the shared line, your shared line button  is solid red and the call displays on your screen.
- When your co-worker puts a call on hold, the session button  on your phone pulses red. You or your co-worker can resume the call.
- If your co-worker enables the **Privacy** feature, his or her calls do not display on your screen.




14 Voicemail

New message indicators:

- A solid red light on your handset.
- A stutter dial tone on the line (if enabled).
- A voicemail icon  next to the line label and session button (may include message count).



Listen to messages


Press the **Messages** button  and follow the voice prompts. Or, press the session button  next to the voicemail icon .

15 Tips


What are the buttons next to my screen?

- The buttons on the left side of your screen are line (and feature) buttons. Line buttons change line views but do not affect calls.
- The buttons on the right side of your screen are session buttons. Each call correlates to a session button. Use session buttons to answer and resume calls or to view call details.


How do I silence my ringing phone?

Press the left side of the volume button  one time while the phone is ringing.


How do I change my ringtone?

1. Select **Applications**  > **Preferences** > **Ringtone**, then select a line and press **Edit**.
2. Select a ringtone and press **Play**, then press **Set**.

How do I change my wallpaper?

Select **Applications**  > **Preferences** > **Wallpaper**. To add custom wallpaper, see your system administrator.

What does the Back button do?

Press the **Back** button  to back out of applications and menus.

Can I use my Bluetooth headset?

The Cisco Unified IP Phone 9951 supports Bluetooth. Your system administrator has details.

Where can I find a complete User Guide?

http://www.cisco.com/en/US/products/ps10453/products_user_guide_list.html

Americas Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



Cisco, Cisco Systems, the Cisco logo, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries. All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0705R)

© 2009 Cisco Systems, Inc. All rights reserved.
Published December 2, 2009, OL-20434-01